



DESCRIPTION

Use ECH₂O Utility software to connect to and to configure your Em50, Em50 Solar, Em50G, Em50G Solar or Em5b data logger.

ECH₂O Utility allows you to:

- Calculate how many days of storage you have based on your preferred measurement interval
- Monitor battery life
- Name data logger, set date, time, and measurement interval, and specify sensors for each port using dropdown menus
- Download both calibrated and unprocessed data to MS Excel or DataTrac

ECH₂O Utility features

- Connect to ECH₂O loggers directly or with radio telemetry
- Set all logger configuration parameters with visual controls
- Make real-time sensor measurements (scan sensors)
- Create Excel or text files with raw or processed data
- Create configuration and data files for use with DataTrac
- Process data downloaded with ECH₂O Utility Mobile
- Test the quality of radio telemetry connections

Minimum computer requirements

- Hard disk with 20 MB of free space
- Windows XP with 128 MB RAM
- Available serial port (or USB to Serial adapter)
- Microsoft Excel 97 or better (if saving data as xls files)